

Phonak Conversation Set

Quick setup guide / Schnellstartanleitung



Guide d'installation rapide / Guía rápida de instalación



PHONAK
life is on

1


Charging
Aufladen
Charger
Cargar



Or
Oder
Ou
O bien


ComPilot Air II

RemoteMic




Wearing / Tragen / Porter / Llevar

ComPilot Air II




RemoteMic





Switching On
Einschalten
Mise en marche
Encender


RemoteMic




ComPilot Air II



Solid blue
Konstant blau
Bleu continu
Azul fijo



Usage
Benutzung
Utilisation
Utilización




ComPilot Air II

RemoteMic



Pause / Resume
Pause / Fortsetzen
Pause / Continuer
Pausa / Reanudar



Volume setting
Lautstärke einstellen
Réglage du volume
Ajuste de volumen



Off

RemoteMic



Off

ComPilot Air II

The Phonak RemoteMic user guide will give you detailed information about the setup.

Die Phonak RemoteMic Gebrauchsanweisung informiert detailliert über den Gebrauch.

Le mode d'emploi Phonak RemoteMic vous donnera des informations détaillées sur l'utilisation.

Las instrucciones de uso del Phonak RemoteMic le darán una información más detallada sobre su uso.

LED status



On
Ein
Marche
Encendido



Low battery
Niedriger Batteriestand
Accumulateur faible
Pila baja



Audio transmission
Tonübertragung
Transmission audio
Transmisión audio



Pause mode
Pause Modus
Pause
Pausa



Pairing mode
Kopplungsmodus
Couplage
Modo de emparejamiento



Phonak AG
Laubisrütistrasse 28
CH-8712 Stäfa
Switzerland

www.phonak.com

