

Serenity Choice[™] Work

The high-end hearing protection from the hearing care specialist







Serenity Choice™ Work reduces the sound level by 24 dB making it safe for 8 hours continuous use in any environment up to 109 dB. Serenity Choice™ Work can be combined with earmuffs in very loud situations where double protection is a requirement.

While other hearing protection can sound muffled and unnatural, Serenity Choice™ Work provides an air passage to the ear, minimizing the occlusion effect while keeping the ear ventilated for optimum comfort.

Product specific benefits

- A perfect fit is guaranteed: Small, medium and large ear tips in package, extra large size available on request.
- Hygienic: Acoustic filters are fitted with advanced mesh technology. They ensure that your ears remain well ventilated at all times.
- Hypoallergenic: ear tips are made from medical grade TPE.
- Value for money: ear tips can be used multiple times.
- Natural: Natural hearing is preserved, which facilitates situational awareness.

24 | 16 SNR | NRR

Sound Reduction:



Situational Awareness:

Product applications

- Suitable for do-it-yourself work, gardening, cleaning
- Reduces heavy equipment, machinery and tooling noise


In the box

- 2 ear tips of each size S, M, L
- Two acoustic filters 24 dB
- Aluminum key-ring carrying case
- Multilingual manual

Certification Data Serenity Choice™ Work (KI 25)

CE	125 (Hz)	250 (Hz)	500 (Hz)	1 (kHz)	2 (kHz)	4 (kHz)	8 (kHz)	Н	М	L	SNR
Mean attenuation (dB)	23.2	22.3	22.7	24.8	30.8	22.5	36.7				
Standard deviation (dB)	3.0	2.6	2.6	3.6	3.3	2.9	3.5	23	22	21	24
APV 95% (dB)	20.2	19.7	20.1	21.2	27.5	19.6	33.2				

ANSI	125 (Hz)	250 (Hz)	500 (Hz)	1 (kHz)	2 (kHz)	3.15 (kHz)	4 (kHz)	6.3 (kHz)	8 (kHz)	NRR
Mean attenuation (dB)	22.1	20.7	20.5	24.3	31.1	31.6	21.8	22.7	33.7	
Standard deviation (dB)	3.0	2.8	3.6	3.8	4.0	5.1	3.2	3.4	4.1	16
APV 98% (dB)	18.1	15.1	13.3	16.7	23.1	-	18.4	-	20.7	



028-2181-02/V2.00/2020-07/NLG © 2020 Sonova AG All rights reserved